

# Hydro-Kleen™

## Concentrate



**KEY FEATURES**

**Condenser Coil Cleaner, Non-Acid**

**Ideal For Cleaning Grease Contaminated Condenser Coils**

**Foams Out Stubborn Deposits From Coils**

**Easy Rinse, Spray Application**

| Part # | Product           | QTY | Size         |
|--------|-------------------|-----|--------------|
| H-1101 | Condenser Cleaner | 4   | 1 Gal Bottle |
| H-1105 | Condenser Cleaner | 1   | 5 Gal Pail   |
| H-1155 | Condenser Cleaner | 1   | 55 Gal Drum  |

Hydro-Kleen is specially formulated for the cleaning and brightening of air conditioning condenser coils. It is non-acidic, non-flammable and contains no toxic petroleum or chlorinated solvents. The surfactants used in Hydro-Kleen are biodegradable.

**Do Not Use On Indoor Coils. Use Only Outdoors.**

**Directions For Use:**

**Tip:** Cleaning action is accelerated if condenser coil is still warm from use.

1. Read entire label & Safety Data Sheet before use.
2. Disconnect all power before working on equipment.
3. Protect surrounding area from over-spray.
4. Using a suitable low-pressure sprayer, dilute Hydro-Kleen with water according to dilution rates above.
5. Always spray downwind with a coarse spray to avoid misting. Spray between fins using horizontal motion, working from the bottom up.
6. Wait 3 to 4 minutes until foam begins to subside and rinse completely with large amounts of water.
7. Flush sprayer completely with water after use.

**DANGER:** May be corrosive to metals. Causes severe skin burns and eye damage.

Keep in original container. Do not breathe mist, vapors, or spray. Wash face, hands, and any exposed skin thoroughly after handling. Wear protective gloves, protective clothing, and eye/face protection.

**FIRST AID:** IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so. Continue rinsing. Immediately call a POISON CENTER/ Doctor.



**Mix 1 Part Cleaner With:**

|                |             |
|----------------|-------------|
| 3 Parts Water  | Heavy Duty  |
| 6 Parts Water  | Medium Duty |
| 20 Parts Water | Light Duty  |

Store locked up. Dispose of contents and container in accordance with all local, regional, and national regulations.

Contains [CAS]: Potassium hydroxide [1310-58-3], sodium hydroxide [1310-73-2], sodium silicate [1344-09-8].