

Enviro-Coil™

Concentrate


KEY FEATURES
Universal Evaporator & Condenser Coil Cleaner
Environmentally Friendly
No Acid, Butyl Ether, Phosphates, Solvents, Sodium or Potassium Hydroxide

Part #	Product	QTY	Size
H-EC01	Universal Cleaner	4	1 Gal Bottle
H-EC05	Universal Cleaner	1	5 Gal Pail

Removes Mold, Mildew, Dust, Soot, Greasy Residue, Lint, and Other Particulate. Improves Indoor Air Quality, Reduces Power Consumption. Safely cleans evaporators and condensers without potential damage to equipment, personnel, or the environment. Unlike strong acid or highly alkaline cleaners that attack metal, Enviro-Coil Cleaner attacks only the dirt build up and leaves metal surfaces clean and free of corrosion.

Directions For Use:

Evaporator Coils: Dilute with 8 parts water (1 pint cleaner per gallon of water). Shut system off. Spray coil thoroughly using a course spray. Wait 5 minutes and resume normal operation. No rinsing required when condensation is present.

Air Cooled Condensers Coils: Useful tip: cleaning is more effective if condenser is still warm from use. Dilute with 4 parts water (1 qt. cleaner per gallon of water). Shut system off. Spray condenser thoroughly with a course spray, saturating all surfaces to be cleaned. Allow cleaner to work for 5 to 10 minutes, then rinse away dirt and contamination with a garden hose using as much pressure as possible. A hose end spray nozzle is ideal for rinsing. Rinse water is not hazardous and will not harm surrounding plants, roofs, or other nearby equipment.

DANGER: Causes severe skin burns and eye damage.

Do not breathe mist/vapors/spray. Wash face, hands, and any exposed skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection.

FIRST AID: IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/Doctor.


Mix 1 Part Cleaner With:

4 Parts Water	Condensers
---------------	------------

8 Parts Water	Evaporators
---------------	-------------

Store locked up. Dispose of contents and container in accordance with all local, regional, and national regulations.

Contains [CAS#]: Sodium metasilicate [6834-92-0], dipropylene glycol monomethyl ether [34590-94-8].