

Hydro-Foam...

BHydroBalance



KEY FEATURES

Condenser Coil Cleaner, Acid Type

Heavy Foaming Cleaner and Brightener

Increases System Capacity

Reduces Head Pressure

Part #	Product	ΟΤΥ	Size	
Fall#	Product	QII	Size	
H-501	Condenser Cleaner	4	1 Gal Bottle	
H-505	Condenser Cleaner	1	5 Gal Pail	
H-555	Condenser Cleaner	1	55 Gal Drum	



Dire TIP:	 Disconnect all power before working on equipment. Protect surrounding area from over-spray. Dilute Hydro-Foam with water according to dilution rates below. Use acid resistant sprayer and coarse spray to avoid misting. Always spray downwind. Spray between fins using horizontal motion, working from the bottom up. Wait 3 to 4 minutes until foam begins to subside and rinse completely with large amounts of water. 		IF SWALLOWED: Kinse mouth. Do NOT induce vomiting. If on SKIN: (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep at rest in a position comfortable for breathing. IF IN EYES: Rinse cautiously with water for	
	Mix 1 Part Cleaner With: 3 Parts Water Heavy Duty 6 Parts Water Medium Duty		 several minutes. Remove contact lenses if present and easy to do. Continue rinsing. Causes severe burns which may not be immediately painful or visible. May cause hypocalcemia (depletion of calcium in the body) which may be fatal. Specialized medical treatment is required for all exposures (read Section 4 of the Safety Data Sheet). Mix only with water. Do not mix with any other product or chemical. Will react with some metals, such as aluminum, tin, or zinc, to form flammable hydrogen gas. 	
	10 Parts Water	Light Duty	Store locked up. Store in well-ventilated place. Keep container tightly closed. Dispose of contents and container in accordance with all local, regional, and national regulations. Contains [CAS]: Hydrofluoric acid [7664-39-3], phosphoric acid [7664-38-2].	





